



* the sheathing applies only to the boxcar, the o.f. car does not have this, move door assy. over 1/32"

** these parts are styrene

McLeod Western Parts:

I will be using all the parts on sprue R-6 (shown at right) except the flat queen posts and the "not sure" parts. The door latches are on sprue R-5.

Photos and information provided by Jerry Kitts of FMW

Sweet Haven Railroad boxcar build addendum 5.0 door details

Richard L. Gardner

scale 1/2" = 1'-0" (twice size for On30)

